

Glass Wall Light

Modern Luxury Bedside and Corridor Sconce

BULB

E27 · max 10 W LED per lampholder ·
LED recommended · not included

SUPPLY

230 V, fixed wiring

USE

Indoor, dry rooms

IN THE BOX

Glass Wall Light
Bracket, screws and wall plugs
No bulb — see below

YOU WILL NEED

Drill, screwdriver, spirit level, voltage
tester
Not confident with wiring? Use a
registered electrician.

CARE

Wipe glass with a soft dry cloth once
cool. Handle by the body, not the
neck.

NEED A HAND?

Write to
thelightheritagelondon@gmail.com
with your order number and a photo.
We reply within one working day.

INSTALLATION · 6 STEPS

*Switch off at the fuse box before you start. If you are not
confident with wiring, use a registered electrician.*

- 1

Switch off at the fuse box and check the circuit is dead.
- 2

Hold the backplate over the cable outlet, level it and mark the
holes (bedside: 120–150 cm from the floor).
- 3

Drill, plug and screw the backplate to the wall.
- 4

Connect brown to L, blue to N, green/yellow to earth.
- 5

Fit the body over the backplate and tighten the grub screws.
- 6

Fit the bulb and shade, switch on.