

Industrial Pendant Light

Vintage Loft Iron Ceiling Light

BULB	SUPPLY	SIZE	USE
E27 · max 10 W LED per lampholder · LED recommended · not included	230 V, fixed wiring	20 / 27 / 100 cm	Indoor, dry rooms

IN THE BOX

Industrial Pendant Light
Bracket, screws and wall plugs
No bulb — see below

YOU WILL NEED

Drill, screwdriver, spirit level, voltage tester
Not confident with wiring? Use a registered electrician.

CARE

Wipe with a soft, dry cloth once cool.
No solvents.

NEED A HAND?

Write to thelightheritagelondon@gmail.com with your order number and a photo. We reply within one working day.

INSTALLATION · 6 STEPS

Switch off at the fuse box before you start. If you are not confident with wiring, use a registered electrician.

- 1

Switch off at the fuse box and check the circuit is dead.
- 2

Fix the bracket to the ceiling.
- 3

Set the drop: feed the cable or chain through the canopy and lock it.
- 4

Connect brown to L, blue to N, green/yellow to earth. Tug each wire to check.
- 5

Lift the canopy over the bracket and secure it.
- 6

Fit the shade and bulb, switch on.