

Travertine Donut Pendant Light

Natural Stone 15cm, Walnut or Light Wood, Wabi Sabi

LIGHT	SUPPLY	SIZE	USE
Integrated LED	230 V, fixed wiring	15 / 180 cm	Indoor, dry rooms

IN THE BOX

Travertine Donut Pendant Light
Bracket, screws and wall plugs

YOU WILL NEED

Drill, screwdriver, spirit level, voltage tester
Not confident with wiring? Use a registered electrician.

CARE

Wipe stone with a dry cloth only — no acidic cleaners.

NEED A HAND?

Write to thelightheritagelondon@gmail.com with your order number and a photo. We reply within one working day.

INSTALLATION · 6 STEPS

Switch off at the fuse box before you start. If you are not confident with wiring, use a registered electrician.

- 1

Switch off at the fuse box and check the circuit is dead.
- 2

Fix the bracket to the ceiling.
- 3

Set the drop: feed the cable or chain through the canopy and lock it.
- 4

Connect brown to L, blue to N, green/yellow to earth. Tug each wire to check.
- 5

Lift the canopy over the bracket and secure it.
- 6

Fit the diffuser, switch on.