

Outdoor Wall Light

Retro Garden Porch Lantern

BULB	SUPPLY	SIZE	USE
E27 · max 10 W LED per lampholder · LED recommended · not included	230 V, fixed wiring	43 cm	Outdoor

IN THE BOX

Outdoor Wall Light
Bracket, screws and wall plugs
No bulb — see below

YOU WILL NEED

Drill, screwdriver, spirit level, voltage tester
Not confident with wiring? Use a registered electrician.

CARE

Wipe glass with a soft dry cloth once cool. Handle by the body, not the neck.

NEED A HAND?

Write to thelightheritagelondon@gmail.com with your order number and a photo. We reply within one working day.

INSTALLATION · 5 STEPS

Switch off at the fuse box before you start. If you are not confident with wiring, use a registered electrician.

- 1

Switch off at the fuse box. Outdoor lights must be earthed and on an RCD.
- 2

Screw the backplate to the wall with rust-proof fixings, cable through the gasket.
- 3

Connect brown to L, blue to N, green/yellow to earth.
- 4

Run clear silicone along the top edge and cable entry.
- 5

Fit the glass or lantern and a weatherproof LED bulb, switch on.