

Oval Loop Wall Light

Gold Glass Globe Sconce

LIGHT	SUPPLY	SIZE	USE
Integrated LED	230 V, fixed wiring	12 cm	Indoor, dry rooms

IN THE BOX

Oval Loop Wall Light
Bracket, screws and wall plugs
Remote control

YOU WILL NEED

Drill, screwdriver, spirit level, voltage tester
Not confident with wiring? Use a registered electrician.

EVERYDAY USE

Remote: on/off, brightness.

CARE

Wipe glass with a soft dry cloth once cool. Handle by the body, not the neck.

NEED A HAND?

Write to
thelightheritagelondon@gmail.com
with your order number and a photo.
We reply within one working day.

INSTALLATION · 6 STEPS

Switch off at the fuse box before you start. If you are not confident with wiring, use a registered electrician.

- 1

Switch off at the fuse box and check the circuit is dead.
- 2

Hold the backplate over the cable outlet, level it and mark the holes.
- 3

Drill, plug and screw the backplate to the wall.
- 4

Connect brown to L, blue to N, green/yellow to earth.
- 5

Fit the body over the backplate and tighten the grub screws.
- 6

Switch on and press ON on the remote within 10 seconds to pair.