# Fabric Wall Light 54cm

*Classic Rod Bedside Sconce*

| BULB | SUPPLY | SIZE | USE |
|---|---|---|---|
| E14 · max 6 W LED per lampholder · LED recommended · not included | 230 V, fixed wiring | 16 / 54 cm | Indoor, dry rooms |

## IN THE BOX

Fabric Wall Light 54cm

Bracket, screws and wall plugs

No bulb — see below

## YOU WILL NEED

Drill, screwdriver, spirit level, voltage tester

Not confident with wiring? Use a registered electrician.

## CARE

Dust the shade with a soft brush. Keep dry and away from flames.

## NEED A HAND?

Write to **thelightheritagelondon@gmail.com** with your order number and a photo. We reply within one working day.

## INSTALLATION · 6 STEPS

*Switch off at the fuse box before you start. If you are not confident with wiring, use a registered electrician.*

1. Switch off at the fuse box and check the circuit is dead.
2. Hold the backplate over the cable outlet, level it and mark the holes (bedside: 120–150 cm from the floor).
3. Drill, plug and screw the backplate to the wall.
4. Connect brown to L, blue to N, green/yellow to earth.
5. Fit the body over the backplate and tighten the grub screws.
6. Fit the bulb and shade, switch on.

Isolate at the fuse box before touching wiring. Keep this guide for future reference. Recycle electrical items and bulbs, never in household waste.

© 2026 The Light Heritage. All rights reserved. This guide and its design are protected by copyright and may not be copied, reproduced or distributed without written permission.