LED Wall Light

6 Heads - Modern Molecular Sconce

LIGHT	SUPPLY	SIZE	USE
Integrated LED 24W	230 V, fixed wiring	60 cm	Indoor, dry rooms

IN THE BOX

LED Wall Light

Bracket, screws and wall plugs

YOU WILL NEED

Drill, screwdriver, spirit level, voltage tester

Not confident with wiring? Use a registered electrician.

EVERYDAY USE

Switch off and on within 3 seconds to change warm / neutral / cool.

CARE

Wipe with a soft, dry cloth once cool. No solvents.

NEED A HAND?

Write to **thelightheritagelondon@gmail.com** with your order number and a photo. We reply within one working day.

INSTALLATION · 6 STEPS

Switch off at the fuse box before you start. If you are not confident with wiring, use a registered electrician.

1. Switch off at the fuse box and check the circuit is dead.
2. Hold the backplate over the cable outlet, level it and mark the holes.
3. Drill, plug and screw the backplate to the wall.
4. Connect brown to L, blue to N, green/yellow to earth.
5. Fit the body over the backplate and tighten the grub screws.
6. Switch on.

Isolate at the fuse box before touching wiring. Keep this guide for future reference. Recycle electrical items and bulbs, never in household waste.

© 2026 The Light Heritage. All rights reserved. This guide and its design are protected by copyright and may not be copied, reproduced or distributed without written permission.