Wood Linear Pendant Light

Modern LED Dining Light

LIGHT	SUPPLY	SIZE	USE
Integrated LED	230 V, fixed wiring	80 / 100 / 120 cm	Indoor, dry rooms

IN THE BOX

Wood Linear Pendant Light

Bracket, screws and wall plugs

Remote control

YOU WILL NEED

Drill, screwdriver, spirit level, voltage tester

Not confident with wiring? Use a registered electrician.

EVERYDAY USE

Remote: on/off, brightness, warm/neutral/cool.

CARE

Wipe with a soft, dry cloth once cool. No solvents.

NEED A HAND?

Write to **thelightheritagelondon@gmail.com** with your order number and a photo. We reply within one working day.

INSTALLATION · 6 STEPS

Switch off at the fuse box before you start. If you are not confident with wiring, use a registered electrician.

1. Switch off at the fuse box and check the circuit is dead.
2. Fix the bracket to the ceiling.
3. Set the drop: feed the cable or chain through the canopy and lock it (about 75 cm above the table).
4. Connect brown to L, blue to N, green/yellow to earth. Tug each wire to check.
5. Lift the canopy over the bracket and secure it.
6. Fit the diffuser, switch on.

Isolate at the fuse box before touching wiring. Keep this guide for future reference. Recycle electrical items and bulbs, never in household waste.

© 2026 The Light Heritage. All rights reserved. This guide and its design are protected by copyright and may not be copied, reproduced or distributed without written permission.