Wrought Iron Chandelier

8-Light Kitchen Island Light

BULB	SUPPLY	SIZE	USE
8 × E14 · max 6 W LED per lampholder · LED recommended, dimmable type · not included	230 V, fixed wiring	105 cm	Indoor, dry rooms

IN THE BOX

Wrought Iron Chandelier

Bracket, screws and wall plugs

No bulb — see below

YOU WILL NEED

Drill, screwdriver, spirit level, voltage tester

Not confident with wiring? Use a registered electrician.

CARE

Wipe with a soft, dry cloth once cool. No solvents.

NEED A HAND?

Write to **thelightheritagelondon@gmail.com** with your order number and a photo. We reply within one working day.

INSTALLATION · 6 STEPS

Switch off at the fuse box before you start. If you are not confident with wiring, use a registered electrician.

1. Switch off at the fuse box and check the circuit is dead.
2. Fix the bracket to the ceiling, into a joist or a fixing rated for the weight.
3. Set the drop: feed the cable or chain through the canopy and lock it (about 75 cm above the table).
4. Connect brown to L, blue to N, green/yellow to earth. Tug each wire to check.
5. Lift the canopy over the bracket and secure it.
6. Fit the shade and bulb, switch on.

Isolate at the fuse box before touching wiring. Keep this guide for future reference. Recycle electrical items and bulbs, never in household waste.

© 2026 The Light Heritage. All rights reserved. This guide and its design are protected by copyright and may not be copied, reproduced or distributed without written permission.